

FP1WH MULTI-FUNCTION METERED AEROSOL DISPENSING SYSTEM

Wall Mounting

For permanent installation, position screws (included) over a wall stud and secure to wall. Double-sided tape is already affixed to the dispenser for use on a CLEAN non-porous surface.

Instructions

1. Open dispenser by pushing the top button (Fig. A) in and pull cover forward. Dispenser cover is hinged at bottom (Fig. B). To clean dispenser cover, simply remove from hinges and wash in warm water with a mild detergent.
2. Insert two fresh D-Cell alkaline batteries (Fig. C) into the designated slot at the top of the unit, making sure the positive (+) and negative (-) ends of the batteries are positioned properly. **CHECK LCD MAKING SURE THE DISPENSER IS IN THE OFF MODE PRIOR TO INSERTING THE CAN.**
3. Setting clock - Press MODE (Fig. D) button until CLOCK Appears in the bottom right corner, then press the hour and minute buttons until the current time appears. **TIME SHOWN IS A 24 HR. MILITARY TIME, I.E 7:00 PM WILL DISPLAY AS 19:00.**
4. Setting on/off time - The unit will operate 24 hours per day unless programmed differently. Press MODE (Fig. D) button until START appears, then press the HOUR (Fig. E) and MIN. (Fig. F) button until the desired start time is on the display. Repeat this procedure for the STOP function setting until the desired stop time is displayed.
5. Setting spray interval - The unit is preset at a 15 minute spray interval, all other desired intervals must be programmed. Press MODE (Fig. D) button until interval appears, then press the MIN. (Fig. F) button until the desired spray interval appears (1-60 minutes).
6. Setting dispenser spray count/can type – The unit is suitable for standard and micro sized 3000 spray cans (30-day) and 9000 spray cans (90-day) but must be programmed so it can alert you when a new refill is needed. If the metered air freshener you are using says 3400 sprays, set this setting to 34 00. If the metered air freshener you are using says 9000 sprays set this to 90 00.
7. To activate the unit press the ON/OFF button (Fig. G), the LED indicator will flash green/red 3 times and the actuating arm will activate 1 time as system check. **TO AVOID BEING SPRAYED WHEN THE UNIT ACTIVATES, DO NOT STAND IN FRONT OF THE DISPENSER.**
8. Close the cover, making sure the Opening Button (Fig. A) is securely in the opening. **DURING NORMAL OPERATION Green LED blinks approximately every 5 seconds. Red LED blinks to indicate it is time to replace the aerosol can. No blinking light indicates the batteries need replaced. IMPORTANT: SPRAY counting mechanism will let you know the number of times the unit has activated (counts to 3,000 in ascending order). This function MUST be reset with each can or battery replacement. This is done by pressing the ON/OFF button (Fig. G) when the SPRAY function is in the display.**

CAUTION: DO NOT EXPOSE EYE TO FRONT OF SPRAY TIP WHEN CHANGING AEROSOL CAN. DO NOT OPERATE THE UNIT WITHOUT AN AEROSOL CAN IN PLACE.

